Austral Surveillance

(image is for reference only, please in kind prevail)

1, camera   2, TF card   3, a microphone   4 and reset hole   5, status indicator
6, switch machine, camera button   7, photo taking, motion detecting key
8, USB interface

← Full Manual
Quick Reference Manual

Charging
1. Plug USB cable into 8. Plug USB into PC or wall charger
2. Charge for 2-3 hours until red light is off

Switching ON or Off, Standby Mode
1. Press and Hold (6) for 3-5 seconds
2. Red and Blue Lights will come on, then blue stays on

Recording Video
1. Press and Hold (6) for 1 second. Blue will flash and switch off
2. Press and Hold (6) for 1 second. Blue will come back on

Playback
1. Switch unit off
2. Plug USB cable into PC
3. Once PC detects card, access DCIM to access recordings

**FOR ASSISTANCE
AUSTRAL SURVEILLANCE
1300 130 508**

Hd multi-function video glasses specification

First of you use the company's products says thank! Before use, please read this manual correct use of this product. In order to better service, this user manual content may change. Because the product performance and function and happen to change without prior notice.

First, shape, buttons

(image is for reference only, please in kind prevail)

1, camera   2, TF card   3, a microphone   4 and reset hole   5, status indicator
6, switch machine, camera button   7, photo taking, motion detecting key
8, USB interface

Second, product introduction
This product is the first high definition digital camera and take pictures with function of the glasses, TF card memory, also known as "glasses camera", can be high quality photos and videos, this product easy operation, a small fine, beautiful and practical, easy to carry, is business, education, security, media, judicial, tourism, medical treatment, life, etc the necessary practical tools, by the customers.

Third, the operating instructions
1, each component description:
1.1, indicator explanation: state indicator light (the 5) share a pervious to light hole, photo blue lights flash a; Conventional camera blue lights flash three times the lights; When motion detecting corolla red light blue flash out three times double lamp; Shutdown blue light flash once the lights; Charge, the lights flashing, full of electricity red light put out.
1.2, button explanation: light touch button (figure 6) used to boot, shutdown and camera. Light touch buttons (the 7) used for taking pictures, motion detecting camera. Reset button (chart 4) achieve return (no response for machine).
1.3, socket explanation: Mini-8 pin USB socket (the 8), used for connecting a computer or charger, is for data transmission, charging and external power supply interface, TF card used for storing files (chart 2)
1.4, a microphone and a camera, microphone (chart 3), used to pick up sound signal; cameras (chart 1), used to pick camera signal.

2, switch machine:
In short on key (figure 6) boot, the camera began to system initialization (right now red, blue lightly, the initial, after the completion of the red light goes out, and blue lights long bright, into standby mode.

3, mode switch:

This machine is no switch mode, can be directly through the key into the corresponding working mode.

4, camera modes: when watch in shutdown state, press the boot key, double light, system after the initial cut red, blue lights long bright, this time the camera into standby mode, and the short press boot key (figure 6), blue lights flashing, in order to save electricity, total twinkle three times, the lights, this time the camera has entered of camera, in the camera of short according to boot key, blue lights long bright, at this time, save the file and stop camera, back to standby mode. In order to better protect files, camera every five minutes save a document.
Note: the camera for cycle camera, please keep it in front of the need to save file, to avoid being behind the file to override.

5 and taking pictures of the mode:
In standby mode, according to take pictures key short (chart 7) namely photograph, each short as a taking pictures key (the 7), blue lights flashing a take a photo and storage, back to take pictures standby mode.

6, motion detecting videotape:
In standby mode, long press photos key (the 7) namely into motion detecting camera. Double flashing, etc. in order to save electricity, flashing after three times, two lights, this time the camera has entered into motion detecting camera. The motion detecting camera, when the object in a camera range mobile, namely open camera, as an object from camera range is suspended after photographing and wait for the next move move objects appear, will again start camera, round and round. So can save disk space.
Note: the camera for cycle camera, please keep it in front of the need to save file, to avoid being behind the file to override.

7, mobile disk:
The machine is equipped with USB extension cord, first connect the unit's USB port (the 8), and the other end to connect to your computer's USB interface, this time the computer will pop up portable disk logo, you also can be in the "my computer" find "mobile disk" set of characters. When the machine connected to computer, the machine as a computer disk has started the movement of the work, you can be very convenient through the computer to check, transmission, copying, deleting files. This machine image file save record for: * disk _DCIM \ 100 DSCIM. Need to uninstall this unit, please click on the task bar portable equipment icon, inside the portable storage devices unloading, let the system can pull out after confirm safety hardware, and the machine and computer connections disconnected
Note: according to the computer configuration or system differences, identifying the mobile disk time will differ slightly, please be patient, this period had better not to the operation of the camera, so as not to affect computer hardware identification, if long time not to recognize mobile disk, please try to insert, if still can't identify the hardware, please confirm your operating system, driver, USB interface, connecting cables is is normal; In order to avoid the machine or computer is caused damage, please in strict accordance with the standard of connection, unloading the machine, connection with accompanied with essential to the USB extension cord connect the unit's USB port (the 8), then linked to the USB port of computer, unloading by hand, please suggests "that can be safely removed from the system equipment", the first computer disconnect USB, To disconnect the USB connection with the machine.

8, computer network camera functions:
First of all you must on your computer to install accompanied with the disc camera driving. The accompanied with the disc into your computer to drive, running the disc STK02N 2.4, Exe on camera driving installation, pack good camera driving can use the computer after a

camera. Hold taking pictures key (the 7), connected to the computer, the machine into the PC Camera (a network of cameras) mode, in this mode, You can conveniently and close friends, shooting video chat purikura, and so on. Open the network cameras paintings Face: double-click my computer ————— (note: this from a USB connection on state can enter into a network of cameras function)
In order to avoid the machine or computer is caused damage, please in strict accordance with the standard of connection, unloading the machine, connection with accompanied with essential to the USB extension cord connect the unit's USB port (the 8), then linked to the USB port of computer, unloading by hand, please suggests "that can be safely removed from the disconnect USB.

9, charging
Connecting a computer via USB or charger, camera can charge when the battery charge in the state, the lights flashing, when a full battery, the red light put out. note: camera with built-in high capacity lithium-ion polymer battery, no memory effect, can follow along with the filling with, but originally the use of the five times before, please use the battery charge after to saturation, to activate the biggest capacity battery, obtain the standard working hours. In order to let the battery storing capacity of the maximization, every time when charging, please indicate in the indicator to maintain full of electricity charge 30 points to 60 minutes. In order to avoid the machine or computer is caused damage, please in strict accordance with the standard of connection, unloading the machine, connection with accompanied with essential to the USB extension cord connect the unit's USB port (the 8), Then linked to the USB charger, computer mouth, unloading, when suggests "that can be safely removed from the system equipment", first of the USB charger or computer, again with the connection of disconnect USB.

10, time to fix:
The video camera provides in the video file video display the function of the time, you need to set up according to actual time, time format for years, Month. Th: points: seconds. Set the method is as follows, connected to the computer, find the mobile disk, in the disk space right click the mouse pointer to the popup menu on the "new"-">" text documents "to the document named for "time "(after must be be lowcase), by extension, called" TXT ", You can also in desktop computer in accordance with the above method to build such a folder and then copy to disk folder. Open time folder, setting time formats such as:2000.01.01 00:00:00, year, month, day and, minutes and seconds when between separated by Spaces. Then save. Save the file safety after exit hardware, boot, time setting complete. Time set, video files of time and you to set a time to……. Note: after the time set to come into force after must be switched on.

11, and exception handling:
Camera storage space is insufficient, green and red light in about 3 seconds and flashing, automatic save the image file and shut down, if you want to continue to use the camera, in the computer image file for backup, and remove the memory of the old files within, to make enough storage space.
Video camera batteries surplus is insufficient, will be in the red light flash about 3 times, save the current image file and automatic shutdown, if you want to continue to use the camera, please charge after use.
Because of the improper operation camera by accident or other special reason to stop response, press the reset button to turn off the power supply (chart 4) and restarting before use.
Can't boot the battery has electric, please charge; Press the reset button to turn off the power supply (chart 4) and restarting before use.
No video: memory card is bad file too much, please format disk before use.

Not united computer: please make sure your operating system, driver, USB interface, the problem is is normal.
Fourth, the relevant parameters

projects	parameters
video formats	AVI
video encoder	M-JPEG
Video Resolution	1280*720 VGA
video frame rate	30fps
image format	JPG
images	2560 x 1920
fun ratio	16 : 9
support system	Windows me/2000 xp 2003/vista: M
battery capacity	160mAh
working hours	about 80 minutes
charge voltage	DC-5V
Interface	2、5、4p in USB
storage support	micro SD card
battery type	High capacity polymer lithium electricity

(specifications may be upgraded, will be updated change the actual phone)

Fifth, Notes:
● Set use scene: please strictly abide by the relevant state laws and may not be used for any illegal this product with way, otherwise the consequence is proud.
● About battery: along with the growth of the use time, batteries work to shorten the time, did not use for a long time, Please prior to the use of full of electricity.
● The player is slightly less than the actual capacity nominal capacity, is a normal phenomenon.
● File security: this product non-professional storage equipment, and does not guarantee that the internal storage the integrity of files and security
Sex, abnormal, please immediately in the computer or other storage device back up your important files.
● Video quality: this product nonprofessional video equipment, do not guarantee all video files effect can meet your Expectations.
● Working temperature: 0-40℃
● Working humidity: 20%-80%, do not send the product in the damp working environment, the product does not have the Water function.
● Shooting intensity of illumination: please in a well-lit environment use, please do not please camera direct to the sun is strong The light source, test optical device is broken.
● Cleaning requirements: do not on the dust density under the environment of the excessive use, in order to avoid the lens and other components with Dye dust, affect camera effect, the camera can wipe with a paper or glasses cloth wipe gently, keep them clean.
● Other necessity: please do not make the product in high electromagnetic field, when electric effect, or take any electron electronic products, please do not make its were hit hard, vibrations; please Don't in strong magnetic field, and heavy use.
● Other matters: this product is precision electronic products, please do not make its were hit hard, vibrations; pleaseDon't in strong magnetic field, and heavy use.
● Waste treatment: please pay attention to environmental protection, don't throw them away this product. The ban this product throwing in fire,
For preventing explosion
● Added: other unknown matters please contact with local dealers.