



CCTVCHARGEIOS and CCTVCHARGEDROID User Manual

Quick Start Guide



1080P FHD APP Based Functional
Charging Dock Wi-Fi Camera

Structures



Notice:

The user name and password of the router should not use special symbols, otherwise the device can not recognize. eg. "hidden" ✓ "+x_hidden" ✗

Features

- Free Apps available for android and iOS smartphone
- Wireless 802.11 b/g/n network connection
- Motion detect video recording
- Push alarm notifications available
- Up to 64GB micro SD card
- Real smartphone charging dock function
- 100 degree camera view angle
- Optional night vision
- 100% covert Wi-Fi DVR
- Actual time/date stampings

01

Please see below for the detailed manual for your Wi-Fi Charging Dock Camera. Instructions are for the iPhone, but Android operation is the same as the iPhone.

Insert Micro SD Card

Insert any brand new 2-64GB Micro SD card to the device.

Please power off the camera before inserting/removing the micro SD card. Failure to do so may result damages to the camera or memory card.

Power On/Off Device

Power On: Just simply connect the device to DC 5V main power adapter.

Power Off: Just simply disconnect the device from DC 5V main power adapter.

Installation:

Download APP on

- App Store: "Fuvision"
- Google Play: "Fuvision2016"

iPhone App.




Android App.




02

1. Use your email address and password to create a new account.



2. Tap "Register" to finish the new account registration. (Email account only for login used.)



3. Use your registered account to login.

Retrieve Password:

If you have forgotten your password:

1. Type your registered email account
2. Tap "Retrieve Password"
3. Check your email to get the new password

Notice: If there is no message in your mail box, please check the SPAM file.

04

Wi-Fi Setting:

1. Settings → Wi-Fi /WLAN → Find device's AP Signal (ET8908*****)





(For the first time connection, it needs to wait for 2 minutes for the Wi-Fi signal to be connected with your phone.)

05

03

1. Use your email address and password to create a new account.



2. Tap "Register" to finish the new account registration. (Email account only for login used.)




3. Use your registered account to login.

Retrieve Password:

If you have forgotten your password:

1. Type your registered email account
2. Tap "Retrieve Password"
3. Check your email to get the new password

Notice: If there is no message in your mail box, please check the SPAM file.




Wi-Fi Setting:


1. Settings → Wi-Fi /WLAN → Find device's AP Signal (ET8908*****)




(For the first time connection, it needs to wait for 2 minutes for the Wi-Fi signal to be connected with your phone.)



2. Open Fuvision / Fuvision 2016 App





(If there is no camera ID listed, please pull down the device list to refresh it until the camera ID shows.)





3. Tap "Setting" Icon

4. Wi-Fi setting




5. Choose your SSID
type your password




6. Tap "Save" (A window will pop up with "Success to configure")

7. Tap "Confirm"


(You will hear a tune from the device once its Wi-Fi connects to your Wi-Fi router. Then the device will be rebooted to finish the Wi-Fi set up. This will be completed within 2 minutes. During the reboot period, the camera ID will disappear from "Device List" window, you can swipe down the device list to refresh and bring up all available cameras. Tap the camera ID to start monitoring.)



Notice: Ensure Wi-Fi signal is strong for installing the camera. If can not connect the Wi-Fi please change a better signal and try again.



Icon Feature



Icon	Features
	Add Camera
	Settings
	Playback
	Delete Camera
	Album (Video and photos)


Share Camera Photo / Video

Follow the steps

1. "Album"


2. "Edit"

3. "Share"



• Reset

1. Turn on the camera, then use the reset pin keep pressing the reset button for at least 10 seconds.
2. Please interval 1-2 mins when reset.



• Micro SD Card Format Class 10 Micro SD Card

Format

To inspect the device whether read the micro SD card:

1. Setting
2. Recording Setting
3. Format SD Card


Status	Indicate
Total capacity 0 User capacity 0	Device is not able to read the micro SD card.
Total capacity 14 User capacity 12	Device read the SD card, but you will need to format SD Card via APP. Please tap "Format SD Card".

Playback



After videos recorded, as playing the same time, it will be automatically downloaded on your phone.

1. Tap "Playback".
2. Choose a video from the list.

Notice: Ensure your device and smart phone are connecting at the same Wi-Fi router.



3. While playing, the video will be saved on your phone, check out in "Album".



Update

Once the system update, open the APP you will receive a notification of software update.